

Reliable®

Installation and Service Wrenches

Sprinkler Wrenches:

Model G4

For Models:


- G4, G4FR, G4QR, F4FR, F4FR-NF & F4/RES Concealed
- RFC 56 Concealed



Model GFR2

For Models:

- F1, F1/EC, F1FR, F1FR/EC & F1/RES/F2 Recessed Pendant
- G/F2 & GFR Recessed
- F1/RES/F2 & G/F1/EC4 Recessed Horizontal Sidewall
- G/F1 & F1FR/EC8&9
- G/F1 Recessed Pendant
- F1&F1FR Intermediate Level Pendant
- Model FP Push-On Recessed Escutcheon for F1 and F1FR Horizontal Sidewall
- Model FP Push-On Recessed Escutcheon for F1 and F1FR Pendants
- DH-80 Recessed
- DH56 Recessed, DH56 Concealed
- F156 and F1FR56 Recessed Pendant
- F1RES 76 Recessed & CCP Pendant
- KFR56 HSW Recessed F1/F2/FP & Concealed
- All Models that used GFR1 wrench



For sprinklers with bulb protectors, the clasp of the bulb protector must be facing out of the wrench as shown.

Model RC1

For Models:

- G Recessed Pendant
- G1 & F1/RES Concealed
- G Intermediate Level Pendant
- F1FR & F1FR QREC Concealed
- F1FR56 & F1FR56 QREC Concealed
- KFR56 Pendant Recessed F1/F2/FP & Concealed CCP



Model ZX Pendant

For Models:

- XL QR, XL INST QR EC



Model XLO EC

For Model:

- G4 XLO QREC/EC Concealed Sprinkler



Model F3

For Models:

- F3/F3QR Dry Pendant & HSW
- DH56 Dry EC HSW


This wrench is similar to the Model D wrench except the wrench opening is keyed and larger. Painted red.



Model XLO2

- F3/F3QR Dry recessed & concealed pendant, HSW & DH56
- GFR VELO Pendant


For sprinklers with bulb protectors, the clasp of the bulb protector must be facing out of the wrench as shown.



Model ZX Horizontal Sidewall

For Models:

- XL QR, XL INST QREC



Model FC Flat Concealed

For Model:

- RFC 30
- RFC 43
- RFC 49
- G5



A 1/2" square drive allows all the preceding wrenches to be driven by the extension and ratchet used with the Model FC Sprinkler Wrench. These wrenches must be used with the sprinklers indicated to minimize the possibility of damaging the sprinkler. The cavity of these wrenches provides sufficient support to the sprinkler to assure a safe, positive installation.

Model D

For Models:

- F1, F1FR, F156, F1FR56, F1RES, KFR56, G & GFR Pendant, Upright & HSW
- F1, F1FR, F156, F1FR56 & G VSW
- KFR-CCS, Upright



The “just right” length of these wrenches provides the proper leverage when tightening sprinklers into pipe fittings—preventing sprinkler damage. The slotted opening prevents wrench slippage which could damage the sprinkler. Painted grey.

Model H

For Models:

- GL112 Upright
- G XLO Upright
- G & GFR VELO Pendant
- GFR VELO ECOH Upright



Similar to Model D, except for wrench opening. Painted blue.

Model N

For Model:

- N252 EC Pendant
- N25 (ESFR)

This wrench is used for both recessed and non-recessed sprinklers.



Model J1

For Models:

- JL-14 (ESFR)
- JL-17 (ESFR)
- J168 Upright
- J112 ECOH Pendant & Upright
- JL112 ECOH Pendant & Upright



Model RJ

For Models:

- J112 Recessed Pendant
- JL112 Recessed Pendant



Model H1

For Models :

- HL-22 (ESFR)



Valve Wrenches:

Model A & D Dry Pipe Valve Seat

Model C1 & C2 Lever Bracket Nut

Made of cast iron. These wrenches are specially designed to be used with Reliable Models A, C1, C2 and D Dry Pipe Valves. When used with C series valves, the lugs on the wrench engage the slots of the Lever Bracket Nut. Removal of this nut permits lifting out the entire clapper assembly. When used with Reliable Models A and D Dry Pipe Valves, the lugs engage ribs in the bronze seat and enable it to be unscrewed.

The 1½” hex boss on the top of the wrench allows it to be used with a standard open end, socket or adjustable wrench. Available in 4” and 6” sizes. The 4” size also fits the Model A 2½” Dry Pipe Valve.



Model E Alarm Valve Seat

Model B & BX

Deluge Valve Seat

Model LDX Dry Pipe Valve Seat

Made of cast iron. Specially designed for easily removing and replacing the valve seat without damaging it. Has spaced slots for engaging seat lugs and a 1” or 1½” hex boss for gripping with a standard open end, socket or adjustable wrench.



Sizes Fit Models E Alarm Valves, B & BX Deluge & LDX Dry Pipe Valves

Wrench Size	Model E	Models B, BX & LDX	Hex Boss
2½”	6881230000	--	1”
3”	6881230000	--	1”
4”	6881240000	6881240000	1½”
6”	6881260000	6881506000	1½”
8”	6881280000	--	1½”

The equipment presented in this bulletin is to be installed in accordance with the latest published Standards of the National Fire Protection Association, Factory Mutual Research Corporation, or other similar organizations and also with the provisions of governmental codes or ordinances whenever applicable.

Products manufactured and distributed by Reliable have been protecting life and property for over 90 years, and are installed and serviced by the most highly qualified and reputable sprinkler contractors located throughout the United States, Canada and foreign countries.

Manufactured by

Reliable®

The Reliable Automatic Sprinkler Co., Inc.

(800) 431-1588

(800) 848-6051

(914) 829-2042

www.reliablesprinkler.com

Sales Offices

Sales Fax

Corporate Offices

Internet Address



Recycled Paper

Revision lines indicate updated or new data.

EG. Printed in U.S.A. 01/14 P/N 9999970036